

Method statement for Cem-Rock™ and tiles application

1. Before boards are installed, ensure supports are secured correctly, and installed at maximum 600mm centres (tile supplier to confirm centres), aligned and levelled.
2. Fix the Cem-Rock™ Boards onto the supports using Greenspan approved Stainless Steel or Alkali Resistant Screws (4x40mm). Screws spacing should not exceed 150mm at the edge of each board and 200mm in the middle of the board. Minimum distance of the screw from the edge of the board is approx. 15mm. Do not countersink screws. Leave a gap of 2mm between the boards to allow for proper joints treatment. Make sure the board is installed rough side out.
3. Apply tiling adhesive to the joints (also at the corners) ensuring the gap between the boards is completely filled.
4. Apply suitable tile primer (i.e. SBR Bond, ThistleBond-it or similar) onto Cem-Rock™ boards' surface (optional).
5. Install the tiling adhesive and tiles to tiles' supplier specification.

For further information contact the Greenspan Technical Department.